



ROCKSHOX Adjusting knob

for rebound, Charger2 RC

Price: 2,12 €

suitable for:ROCKSHOX BoXXer C1 (mod.19+)ROCKSHOX Lyrik RCT3 / RC / RC2 A1-C2 (mod.16-19)ROCKSHOX Lyrik Select / Select+ / Ultimate C2-C3 (2020-2021)ROCKSHOX Pike A1-A2 (2014-2017)ROCKSHOX Pike Boost 15 x 110 A2 (2017)ROCKSHOX Pike DJ A2 (2016-2018)ROCKSHOX Pike RCT3 / RCT / RC B1-B2 (mod.18-19)ROCKSHOX Pike Select / Select+ / Ultimate (mod.20-21)ROCKSHOX ZEB A1 (2021)

Datos maestros

Número de artículo del proveedor:	11.4018.082.004
EAN	710845812446
UVP	32,00 €
DST-Code	2005
Fedas-Code	160300
Bidex-Code	201090
SB-Artículo	No
Marca/Proveedor	ROCKSHOX
Unidad de medida:	PIECE
Weight	0.012 kg

Datos técnicos

Artículo	Ersatzteil
Color principal	Negro