

tecMATE Battery tester "Optimate Test"

tests battery and dynamo voltage

Usage:

1. Check the state of battery. An insufficiently charged battery is only partially able to start an engine

2. Start the motor. OptiMate TEST recorded the lowest starting voltages and displays (for 20 sec.)

3. Check the charging voltage of the generator and voltage regulator when the engine is running

TIP: Low charge voltage leads to bad battery performance. A high charging voltage leads to a lead-acid battery to excessive gas formation and damages it. High charging voltage at a LiFePO4 and lithium-ion battery causes strong damages.

RRP: 68,80 €

Datos maestros

Número de artículo del proveedor:	TS120N
EAN	5425006141857
UVP	68,80 €
Número de registro RAEE	DE19067175
SB-Artículo	No
Marca/Proveedor	tecMATE
Unidad de medida:	PIECE
Weight	0.155 kg

Datos técnicos

Artículo	Article
Color principal	Negro
Color secundario	Rojo
Longitud cable de carga	1000 mm
Tensión	12V
Tipo de batería	AGM , gel , Lithium-Ion (LiFePO4) , standard
Tipo de conexión	crocodile clamps
Versión	battery diagnosis
Ámbito de aplicación	motorcycle , scooter